

Full Installation and user guide

Welcome to UPDD Windows desktop specific installation instructions and related notes for UPDD version 6

Development history can be viewed from the [UPDD Daemon menu](#), Change History option.

These notes should be followed to install the UPDD 6 pointer device driver on Windows Desktops running Windows, 2003, XP/XPe, Windows 64 bit, Vista 32 / 64 bit and Windows 7, 8 and 10 32 / 64 bit.

Touch-Base Support

<http://support.touch-base.com/Documentation/50132/Full-Installation-and-use...>