

Uninstall

1. There are a few simple steps to manually uninstall the gesture software:

Remove the start up item if gestures have been configured to be invoked at start up:

Invoke the Gesture GUI via the [Gesture Menu item, Settings entry.](#)

Select the [Other Settings dialog.](#)

Uncheck the 'Start UPDD Gestures at login' option.

2. Quit Gestures

Invoke the Gesture GUI via the [Gesture Menu item, Settings entry.](#)

Select the Quit option.

3. Delete the application

Locate and drag the gesture application to the trash can.

Touch-Base Support

<http://support.touch-base.com/Documentation/50169/Uninstall>